



Five-second PLC wiring system

Cut your PLC wiring time down to minutes instead of hours

The ZIPLink wiring system eliminates the normally tedious process of wiring PLC I/O to terminal blocks. Simply plug one end of a ZIPLink pre-wired terminal block cable into your CLICK module and the other end into a ZIPLink connector module. It's that easy. ZIPLinks use half the space, at a fraction of the total cost of terminal blocks.

ZIPLinks are available in a variety of styles to suit your needs, including feedthrough connector module*. ZIPLinks are available for all CLICK CPU modules and all discrete input and output modules.

**Note: only the feedthrough module ZIPLink currently available.*

Specify your ZIPLink system

Use the Compatibility Matrix table below:

Step 1	Locate the CLICK CPU module or I/O module part number.
Step 2	Locate compatible connector module type.
Step 3	Select the cable length by replacing the # symbol with: Blank = 0.5m, -1 = 1.0m, -2 = 2.0m

ZipLink Wiring System Compatibility Matrix for CLICK PLCs				
		Step 2: Connector Module Type		Feedthrough Module
		Step 1: I/O unit	Number of Terminals	Step 3: Cables
CPU Module	CO-00DD1-D	20		ZL-C0-CBL20#
	CO-00DD2-D	20		ZL-C0-CBL20#
	CO-00DR-D	20		ZL-C0-CBL20#
	CO-00AR-D	20		ZL-C0-CBL20#
I/O Module	CO-08ND3	11		ZL-C0-CBL11#
	CO-08NA	11		ZL-C0-CBL11#
	CO-08TD1	11		ZL-C0-CBL11#
	CO-08TD2	11		ZL-C0-CBL11#
	CO-08TR	11		ZL-C0-CBL11#
	CO-08TA	11		ZL-C0-CBL11#
	CO-16ND3	20		ZL-C0-CBL20#
	CO-16TD1	20		ZL-C0-CBL20#
	CO-16TD2	20		ZL-C0-CBL20#
	CO-04TRS*	20		ZL-C0-CBL20#

**Note: The CO-04TRS relay output is derated to 2A per point max. when used with the ZipLink wiring system*

